

## AG-SELECT MENU GUIDE

FACTORY RESET AG-SELECT B1

## **Factory Reset AG-Select B1**

- 1. Power off instrument
- 2. Power instrument back up
- 3. Press OK button within 15 seconds
- 4. After screen has changed hold down the MINUS and PLUS buttons simultaneously
- 5. "SET DEFAULTS" should be shown on screen, if you do not see "SET DEFAULTS" start again taking extra care on step 4
- 6. Press PLUS, PLUS, RIGHT ARROW to start a full reset or MINUS, MINUS, RIGHT ARROW for a partial reset

